



SPARK PLUG




Inspection guideline (Replace if necessary)

Interval		
100 hours	6 months	*whichever comes first
Replacement 200 hours (if necessary)	1 year	*Only DF325A/ DF300B

*This guideline may vary by outboard motor model, condition of use, region, etc. Please refer to the owner's manual or ask an authorized Suzuki dealer for more information.

Purpose and Function

The spark plug generates electric sparks for igniting the air-fuel mixture inside the engine cylinder. Clean spark plug prevents abnormal combustion.



If overused without replacement ...

- **Hard to start the engine**
- **Decrease in engine power**
- **Decrease in fuel economy**

As spark plug electrodes degrades or becomes contaminated, the ignition spark becomes weaker, which increases fuel consumption and the possibility of engine malfunction.

* When you replace a spark plug, it is essential to use a new plug of the size and heat range specified in the owner's manual.