



# FUEL FILTER



## Replacement guideline

	Interval		
Low pressure fuel filter	400 hours	2 years	*whichever comes first
High pressure fuel filter	1000 hours	-	-

## Purpose and Function

It prevents the dust, rust and so on in fuel tank from being inhaled into the fuel system.

(For your reference, fuel filter with the function to detect water contained in fuel is a standard equipment for large-sized Suzuki outboard motors.)



### If overused without replacement ...

- When dust and rust clog up in fuel pump, carburetor and fuel injection devices (injector etc.), it causes difficulties to supply enough fuel necessary for normal combustion.

**As a result, starting failure, idling instability, power decline and so on are caused.**

When keep using for a long time, filtration efficiency may fail and impurities may flow into fuel system.

Periodical cleaning or replacement is necessary.

## FOR YOUR GREATER COMFORT

### WATER SEPARATOR / FUEL FILTER

65900-98J00-000  
Applicable Model DF8A-300AP, DT9.9A-40W/WR/WK



Suzuki also highly recommends that you install a **water separator** assembly between your boat's fuel tank(s) and outboard motor(s).

No difficulties are needed to mount this state-of-the-art filter in the fuel line, and it starts removing water and all the other contaminants from the fuel before they reach your engine(s).

It features a transparent removable bowl for easy viewing of fuel condition and a drain valve for water and other impurities.

### ELEMENT SET

65910-98J00-000  
Applicable Model DF8A-300AP, DT9.9A-40W/WR/WK

The filter element set is also separately available for periodic replacement.

